

## REAR HUB REPAIR RACE & BEARING

1. Apply loctite quick metal to the outside of the new race and the inside of the old hub race.
2. Press race to the **BOTTOM** of the old hub with a 10 ton hydraulic press.
3. Wipe excess loctite out of the bottom of the hub and clean the new race of any loctite with lacquer thinner.

### **BRATTON'S** **ANTIQUE AUTO PARTS**



**800-255-1929 Phone**  
**[www.brattons.com](http://www.brattons.com)**

800-774-1930 Fax  
1606 Back Acre Circle  
Mount Airy, MD 21771

*Your source for Quality Model A Ford Parts since 1976*