

CORRECT PROCESS TO UPSET FERRAL

1 Set ferral 1/16"
from end of tube

2 Mark gas line
at end of nut

At final tightening of nut be sure
to align mark at end of nut

