

P/N 21340 1930 Thru Sept. 1930 Fender Bolt Set

➤ *Rear Fender To Body*

8	5/16 -18 Hex Nut
8	5/16 Flat Washer
8	5/16 Lock Washer

➤ *Front Fender To Splash Apron*

10	1/4 - 20 x 5/8 Hex Bolt (<i>Bolt head faces Forward</i>)
10	1/4 - 20 Hex Nut
20	1/4 Flat Washer
10	1/4 Lock Washer

➤ *Rear Fender To Splash Apron*

4	1/4 - 20 x 9/16 Large Head Carriage Bolt (<i>Bolt Head Faces Outward</i>)
4	1/4 - 20 Hex Nut
8	1/4 Flat Washer
4	1/4 Lock Washer

➤ *Front Fender To Running Board*

6	1/4 - 20 x 5/8 Hex Bolt (<i>Bolt head faces Forward</i>)
6	1/4 - 20 Hex Nut
12	1/4 Flat Washer
6	1/4 Lock Washer

➤ *Rear Fender to Running Board (*Bolt head faces to **Rear***)*

4	5/16 -18 x 3/4 Carriage Bolt
4	5/16 -18 Hex Nut
4	5/16 Flat Washer
4	5/16 Lock Washer

➤ *Fender Bead*

4	1/4 - 20 x 3/4 Carriage Bolt
4	1/4 - 20 Hex Nut
4	1/4 Lock Washer

➤ *Splash Apron To Frame*

4	1/4 - 20 x 3/4 Step Bolt (<i>Flatter Head That Carriage Bolt</i>)
4	1/4 - 20 Hex Nut
4	1/4 Lock Washer