

p/n 21350 Sept.1930 Thru 1931 Fender Bolt Set

➤ *Rear Fender To Body*

8 5/16 -18 Hex Nut
8 5/16 Flat Washer
8 5/16 Lock Washer
4 3/8 - 16 x 1 Hex Bolt
4 3/8 - 16 Hex Nut
4 3/8 Flat Washer
4 3/8 Lock Washers

➤ *Front Fender To Splash Apron*

12 5/16 - 18 x 3/4 Hex Bolt (Bolt head faces **Forward**)
12 5/16 - 18 Hex Nut
24 5/16 Flat Washer
12 5/16 Lock Washer

➤ *Rear Fender To Splash Apron*

4 5/16 - 18 x 3/4 Hex Bolt (Bolt Head Faces **Out**)
4 5/16 - 18 Hex Nut
8 5/16 Flat Washer
4 5/16 Lock Washer

➤ *Front Fender To Running Board*

6 5/16 - 18 x 3/4 Hex Bolt (Bolt head faces **Forward**)
6 5/16 - 18 Hex Nut
12 5/16 Flat Washer
6 5/16 Lock Washer

➤ *Rear Fender to Running Board (Bolt head faces to **REAR**)*

4 5/16 - 18 x 3/4 Carriage Bolt
4 5/16 - 18 Hex Nut
4 5/16 Flat Washer
4 5/16 Lock Washer

➤ *Fender Bead*

4 1/4 - 20 x 3/4 Carriage Bolt
4 1/4 - 20 Hex Nut
4 1/4 Lock Washer

➤ *Splash Apron To Frame*

4 1/4 - 20 x 3/4 Step Bolt (Flatter Head Than Carriage Bolt)
4 1/4 - 20 Hex Nut
4 1/4 Lock Washer