



A-18200-B 30-31 OPEN CAR
WIND WING BRACKET SET.



1. Assemble the various pieces as per the drawing enclosed.
2. Measure and mark the windshield post where the studs will be located.
3. Using a small piece of masking tape to protect the chrome finish. tape over the area to be drilled and mark with a center punch.
4. Drill with a $17/64$ " bit and tap holes with $5/16$ " - 24 (N.F.) tap.
5. Cut a template from $1/4$ " material (plywood or fiber board) the same size as the glass that will be installed. Assemble the gripper and install the template.
6. Check all clearances to make sure wind wings will open properly.
7. Install glass.
8. Do not over-tighten. This will provide some flexibility and prevent breakage.