

BRATTON'S

ANTIQUe AUTO PARTS



800-255-1929 Phone
www.brattons.com

800-774-1930 Fax
1606 Back Acre Circle
Mount Airy, MD 21771

Your source for Quality Model A Ford Parts since 1976

How to make the 1930-31 Moto-Meter (25600/25710) and 1930-31 Quail (25750/25770) to fit on the reproduction radiator neck. The repro necks are .085 wider toward the center than the original necks, therefore the tab holder will need to be cut back .085 so the cap will fit on to the repro neck. This can be done by using a Dremel tool.

