



A 35244

ACCELERATOR ROD GROMMET

Install grommet by sliding it down the accelerator rod to the floor board. Tack in place with the four tacks provided. Original grommets were nailed to the floor board in two different patterns. Use either pattern A or B to secure grommet.