

Forming Rain Gutters #29470

Trace gutter curve on the body to a piece of paper. Copy the curve to a 2"x 10" piece of wood block, cut radius out of block with a jigsaw. Nail a larger sheet of plywood to the 2"x10" block. The "J" gutter is extra long, therefore place one hand at end of "J" molding the other hand about 2 1/2 feet apart. You can waste the 6"-8" where your hand is located. Slide gutter across plywood and pull it against the block to form the curve. The flat tacking strip should be cut half way across every 1/2 inch to be able to bend along the curve.

BRATTON'S

ANTIQUE AUTO PARTS



800-255-1929 Phone
www.brattons.com

800-774-1930 Fax
1606 Back Acre Circle
Mount Airy, MD 21771

Your source for Quality Model A Ford Parts since 1976