

36070 PLACEMENT LOCATIONS

FOR COUPES - Original wood frame, place clip 2 1/2" from front. Repro wood is 4" wide, place clip 2" from front. The high edge of the clip is at the front.

FOR: TUDOR SEDAN REAR SEAT- Locate front edge, 1 3/8" from front and 2 1/4" from side. The high edge of the clip is to front. Need 2 clips per seat.

FOR SLANT WINDOW 4 DOORS - The edge of clip is located 2 5/16 from front of wood frame and 4 5/8" from back edge of clip and side of wood frame.